

Thank you for purchasing a *Wall Inspiration*. You will find this application guideline sheet helpful in placing and transferring your graphics on the wall.

Prior to placing the graphic on the wall, please wash the area with a standard household cleaner to ensure the area is free from any dirt or grease.

Before starting step 1 below, take a moment and rub down the premask onto the graphic as it lays flat on a table. Simply place the graphic face up on a hard surface and take the application card (or credit card) and press firmly across the top cover premask over the area where the lettering is.



## 1 Tape graphic temporarily in place

Align graphic and tape in place with a couple small tabs of masking tape or painters tape.



## 2 Make a hinge

Tape across the top of the graphic from edge to edge with masking tape or painters tape, making a hinge. Make sure tape is secured to both premasked graphic and the wall. Remove the small tabs of tape used to initially position graphic.



## 3 Enlist help for larger graphics

Work as a team in removing the graphic backing making sure the graphic doesn't prematurely stick to any surfaces prior to application with a squeegee. Peel the backing off slowly making sure the cut graphic stays together on the top premask.

## Plastic squeegee

The next step requires a plastic squeegee for best results. Use the plastic card included with the graphic or substitute with a credit card or similar flat, fairly rigid object.

Note: you may apply the graphic with just the pressure from your hands pressing slowly across the graphic from side to side as you work down from top to bottom. The graphic should still be burnished down with a card afterwards prior to removing the premask.



## 4 Teamwork Application

While one person holds the graphic just off the surface, the other person works the squeegee back and forth, contacting the graphic to the surface.



## 5 Caution!

Squeegee slowly, working the air out. Do not let the graphic touch the surface before the squeegee presses it in place.



## 6 Remove premask

Always remove the premasking slowly pulling at 180 degrees in the opposite direction.



## Finished product

Working slowly with attention to detail will reward you with professional results and great satisfaction!